

WM20

INSTRUCTION MANUAL

MANUALE D'ISTRUZIONI

BETRIEBSANLEITUNG

MANUEL D'INSTRUCTIONS

MANUAL DE INSTRUCCIONES

BRUGERVEJLEDNING

Introduction 7

Information property	. 7
Safety messages	. 7
General warnings	. 7
Service and warranty	. 7
Description	. 8
Components	. 8
Breakdown of code key of main unit (rear of unit)	. 8
Breakdown of code key of compatible accessory modules	
(rear of module)	. 9
Breakdown of code key of pre-assembled WM20 (rear of main unit)	. 9
Possible configurations	. 10

Description of main unit 11

Main unit - front	11
Main unit - rear	11
Main unit - accessories	12
Measurement menu display	12
Settings and reset menu display	12
Information menu display	13
Information and warnings	13

Description of accessory modules 14

Digital output modules	. 14
Communication modules	. 14

Use: Menu description 15

Measurement menu	15
List of meters	15
List of measurement pages	15
Settings menu	19
Default values of alarm parameters	27
Default values of digital output parameters	27
Information menu.	27
Reset menu	29

Use: how to work 30

Navigating the menus	. 30
Common operations	. 30
Specific operations	. 31
Setting a parameter	. 32
Running a pulse transmission test	. 32
Resetting maximum and average values	. 33
Resetting total energy meters	. 34
Identifying the variable in alarm status	. 35
Troubleshooting	35

Essential information 39

Numerical parameters	
Address parameters	
Alarm settings	41
Filter settings	
Configuration mode	43
Enabling the accessory modules	44

Configuring digital output modules		7
Maintenance and disposal 46		Ш
Cleaning		
Responsibility for disposal		
Common specifications 47		
General features		
Input and output insulation		
Environmental specifications		
Main unit specifications 49		
General features		
Electrical specifications		
Measurement accuracy		
Power supply	53	
LED	54	
Digital output module specificatio	ons 55	
General features		
Static output module (M O O2)		
Relay output module (M O R2)		
Communication module overview	56	
General features		
M C 485232 module		
M C ETH module		
M C BAC IP module		
	WM20 © 2019 CARLO GAVAZZI Controls SpA	5

M C BAC MS module	60
M C PB module	61

Conformity 62

Firmware revision 63

Download 63

FIGURES 381

WM20 - Instruction manual

Power analyzer for three-phase systems

Introduction

Information property

Copyright © 2016, CARLO GAVAZZI Controls SpA

All rights reserved in all countries.

CARLO GAVAZZI Controls SpA reserves the right to apply modifications or make improvements to the relative documentation without the obligation of advance notice.

Safety messages

The following section describes the warnings related to user and device safety included in this document:

NOTICE: indicates obligations that if not observed may lead to damage to the device.

General warnings



THIS manual is an integral part of the product. It should be consulted for all situations related to installation and use. It must be kept in good condition and in a clean location accessible to all operators.

NOTICE: no person is authorized to open the analyzer. This operation is reserved exclusively for CARLO GAVAZZI technical service personnel.

Service and warranty

In the event of malfunction, fault, requests for information or to purchase accessory modules, contact the CARLO GAVAZZI branch or distributor in your country.



Description

WM20 is a modular power analyzer for single, two and three-phase systems.

It is made up of a maximum of three components: main unit that displays measurements on the LCD display with management of two alarms, and two accessory modules, one with digital outputs and the other for communication. The digital output module associates alarms with static or relay outputs and/or transmits pulses proportional to energy consumption. The communication module lets you configure the analyzer and transmit data using a different communication protocol according to the version.

Components

The WM20 is made up of the following components:

Module		Description		
WM20		Main unit, measures With LCD display an measurementparame manageup to two ala	fain unit, measures and displays main electrical variables. Vith LCD display and touch keypad, it lets you set neasurementparameters, configureaccessory modules and nanageup to two alarms.	
Digital outputsAccessory module with two digital outputs. Expands main u capacity, specifically allowing you to:• transmit pulses proportional to energy consumption• control digital outputs (static or relay according to the mo		s. Expands main unit consumption ccording to the module)		
Communication Accessory module that lets you transmit data to other systems configure the analyzer from remote		data to other systems or		
Breakdow	n of c	code key of main u	unit (rear of unit))
WM20 A	Vx		3	а

Model	AV4: From 380 to 690 V L-L ac, 1(2) A, connection via CT AV5: From 380 to 690 V L-L ac, 5(6) A, connection via CT AV6: From 100 to 230 V L-L ac, 5(6) A, connection via CT AV7: From 100 to 230 V L-L ac, 1(2) A, connection via CT	 System: balanced and non-balanced three-phase with 3 or 4 wires Two-phase (3-wire) Single-phase (2-wire) 	 H: auxiliary power supply from 100 to 240 V ac/dc L: auxiliary power supply from 24 to 48 V ac/dc
-------	--	---	--

Breakdown of code key	of compatible accessory modules
(rear of module)	

Code key	Туре	Module description
M O O2		Double static output
M O R2	Digital outputs	Double relay output
M C 485232		Modbus RTU communication on RS485/RS232
M C ETH		Modbus TCP/IP communication on Ethernet
M C BAC IP	Communication	BACnet IP communication on Ethernet
M C BAC MS		BACnet MS/TP communication on RS485
МСРВ		Profibus DP V0 communication on RS485

Breakdown of code key of pre-assembled WM20 (rear of main unit)WM20 AVx 3aaaaaXX

Same as code key of main unit, see "Key to code key of the main unit (rear of unit)" on page 8	Output type: XX: none O2: double static output R2: double relay output	Communication type: XX: none S1: RTU Modbus communication on RS485/RS232 E2: TCP/IP Modbus communication on Ethernet B1: BACnet IP communication on Ethernet B3: BACnet MS/TP communication on RS485 P1: Profibus DP V0 on RS485	No option included
---	---	--	--------------------------

Possible configurations				
WM20 only	WM20 + 1 module	WM20 + 2 modules		

NOTICE: maximum 1 module per type. In the configuration with 2 modules, the communication module is installed last.

 $10 \qquad \mathsf{WM20} \ | \ \textcircled{\texttt{O}} \ \texttt{2019} \ | \ \textbf{CARLO} \ \textbf{GAVAZZI} \ \textbf{Controls} \ \textbf{SpA}$

Description of main unit

Main unit - front			
Fig. 1	Area	Description	
	Α	Optical port and plastic support for OptoProg (CARLO GAVAZZI) connection	
	В	Backlit LCD display	
	c LED that blinks with frequency proportional to active energy consumption, see "LED" on page 54		
	D	Touch keypad	

Main u	Main unit - rear		
Fig. 2	Area	Description	
	Α	Detachable power supply terminals	
	В	Detachable current input terminals	
	С	Detachable voltage input terminals	
	D	Rotary selector to lock configuration: position 1: configuration via keypad or communication enabled (icon on display) position 7: configuration via keypad or communication locked (icon on display)	
	Е	Local bus port for accessory modules	
	F	Power supply status LED, see "LED" on page 54	

Main unit - accessories				
Fig. 3	Area	ea Description		
	Α	Sealable terminal caps		
	В	Lateral brackets		

Measurement menu display			
Fig. 4	Area	Description	
	Α	Area for energy meters and operating hours with relative unit of measurement, see "List of meters" on page 15. These are displayed independently from the contents displayed in area C .	
B Area for warnings and messages, see "Information and warn on page 13		Area for warnings and messages, see "Information and warnings" on page 13	
	С	Area for electrical variable measurements and relative units of measurement (x 3 lines), "List of measurement pages" on page 15. These determine the measurement page.	

Settings and reset menu display			
Fig. 5	Area	Description	
	Α	Page title, see "Settings menu" on page 19 and "Reset menu" on page 29	
	B Page title, see "Settings menu" on page 19 and "Reset menu" or page 29		
	С	Current value/option. Blinks when in edit mode.	
	D	Possible value/option range	

 $12 \qquad \mathsf{WM20} \ | \ \textcircled{\texttt{O}} \ \texttt{2019} \ | \ \textbf{CARLO} \ \textbf{GAVAZZI} \ \textbf{Controls} \ \textbf{SpA}$

Information menu display			
Fig. 6	Area	Description	
	Α	Page title, see "Information menu" on page 27	
	В	Area for warnings and messages, see "Information and warnings" on page 13	
	С	Information on current page	

Information and warnings			
Symbol	Description		
6/6	 Configuration status: locked: rotary selector at rear of main unit in position 7 enabled: rotary selector at rear of main unit in position 1 		
RX/TX	Communication status (reception/transmission)		
\odot	Voltage connection error (inverted sequence)		
THD%	The measurements displayed are total harmonic distortions (THD) expressed as a percentage		
dind	The measurements displayed are average values		
Max	The measurements displayed are maximum values		
A	 Warning of at least one active alarm: permanent: on the information menu page related to the active alarm and activated digital output where relevant blinking: on the measurement menu pages 		

N Ш

Description



Feedback after pressing a button

Description of accessory modules

Digital	Digital output modules			
Fig.7	Area	Description		
	Α	Main unit fastening pins		
	B Detachable digital output terminals			
	С	C Local bus port for communication module		
	D	Local bus port for main unit connection		

Communication modules

NOTE: the image refers to the M C BAC MS module.

Fig.8	Area	Description	
	A	Communication port area NOTE: the communication ports depend on the communication module, see "Communication module overview" on page 56.	
	В	Main unit fastening pins	
	С	Communication status LED (M C 485232, M C BAC MS, M C PB), see "Communication module overview" on page 42.	
	D	Local bus port for main unit or communication module connection	

Use: Menu description

Measurement menu

The measurement menu contains all pages used to display meters and other electrical variables.

List of meters

A list of the meters displayed is provided below:

- kWh Total imported active energy
- kvarh Total imported reactive energy
- kWh -- Total exported active energy
- kvarh -- Total exported reactive energy
- **h** Load operating hours with current absorption exceeding the set threshold, see "Settings menu" on page 19

NOTE: the analyzer also manages the partial meters of active and reactive energy, both imported and exported. Partial meters can only be viewed and reset via communication. List of measurement pages

NOTE: the measurements available depend on the type of system set, see "**Settings menu**" on page 19.

Measurements displayed on page	Page code
$V_{LL\Sigma}$ System phase-phase voltage A_{Σ} System current W_{Σ} System power	01

Measurements displayed on page	Page code
 W₁ Phase 1 active power W₂ Phase 2 active power W₃ Phase 3 active power NOTE: the button can be used to display the average, the maximum values and the average maximum values. 	02
 VA₁ Phase 1 apparent power VA₂ Phase 2 apparent power VA₃ Phase 3 apparent power NOTE: the button can be used to display the average, the maximum values and the average maximum values. 	03
 VAr₁ Phase 1 reactive power VAr₂ Phase 2 reactive power VAr₃ Phase 3 reactive power NOTE: the button can be used to display the average, the maximum values and the average maximum values. 	04

Measurements displayed on page	Page code
$ \begin{array}{c} \textbf{W}_{\sum} \text{ System active power} \\ \textbf{VA}_{\sum} \text{ System apparent power} \\ \textbf{VAr}_{\sum} \text{ System reactive power} \\ \textbf{NOTE: the button } \begin{array}{c} & & \\ & & $	05
 PF₁ Phase 1 power factor PF₂ Phase 2 power factor PF₃ Phase 3 power factor 	06
Hz Frequency PF _Σ System power factor A _N Neutral current	07
thd% * A ₁ THD of phase 1 current A ₂ THD of phase 2 current A ₃ THD of phase 3 current	08
thd% * V1 THD of phase 1 voltage V2 THD of phase 2 voltage V3 THD of phase 3 voltage	09

Measurements displayed on page	Page code
thd% * V ₁₂ THD of phase 1-phase2 voltage V ₂₃ THD of phase2-phase3 voltage V ₃₁ THD of phase3-phase1 voltage	10
$V_{LL\Sigma}$ System phase-phase voltage $V_{LN\Sigma}$ System phase-neutral voltage A_{Σ} System current	11
 A₁ Phase 1 current A₂ Phase 2 current A₃ Phase 3 current NOTE: the button can be used to display the average, the maximum values and the average maximum values.	12
 V₁ Phase 1 voltage V₂ Phase 2 voltage V₃ Phase 3 voltage 	13
 V₁₂ Phase 1-phase2 voltage V₂₃ Phase 2-phase3 voltage V₃₁ Phase 3-phase1 voltage 	14

NOTE *: up to 32nd harmonic.

 $18 \qquad \mathsf{WM20} \ | \ \texttt{\textcircled{O}} \ \texttt{2019} \ | \ \textbf{CARLO} \ \textbf{GAVAZZI} \ \textbf{Controls} \ \textbf{SpA}$

Settings menu

The settings menus contain all pages used to set parameters of the main unit and accessory modules.

NOTE: default values are underlined. Presence of the pages depends on the installed accessory modules. For more information on configuration methods, see "Configuration mode" on page 43.

Page title	Sub-menu title	Description	Values
Password?	-	Enter current password	Current password
Change pass	-	Change password	Four digits (from 0000 to 9999)
Backlight	-	Display backlight time (min)	0: always on From 1 to 255 (<u>2</u>)
M O R2 M O O2 MC485232 MCETH MCBAC IP MCBAC MS MCPB		Module enable	Yes/No Auto: indicates that the module is automatically recognized by the system, see "Enabling accessory modules" on page 44

Page title	Sub-menu title	Description	Values		
System	System - System type		stem - System type (2-wire)/ 2F system (3-wire)/ 2F system (3-wire)/ 2F share system (3-wire)/ 2F system (1P : single-phase system (2-wire)/ 2P : two-phase system (3-wire)/ 3P : three- phase system (3-wire)/ 3P.1 : three-phase system (3-wire), balanced load/ 3P.2 : three- phase system (4 -wire), balanced load/ 3P.n : three- phase system (4 -wire)
Ct ratio	-	Current transformer ratio (CT)	From 1 to 9999		
Pt ratio	Pt ratio - Voltage transformer ratio (VT/PT)		From 1 to 9999		
Dmd	d - Average power calculation range (min)		From 1 to 30 (<u>15</u>)		
Home page	-	Measurement page displayed on access to measurement menu and after 120 seconds of disuse	0: measurement pages displayed in sequence with an interval of 5 s From 1 to 14 To check the page codes, see "List of measurement pages" on page 15		

Page title	Sub-menu title	Description	Values
Filter *	Filter s	Interval of filter intervention with respect to full scale (%)	From 0 to 100 (<u>2</u>)
	Filter co	Filter coefficient	From 1 to 256 (<u>2</u>)
Run hour	_	Current threshold for calculating load operating hours	From <u>0.001</u> A to 9999 MA
Optical	Baudrate	Baud rate (kbps)	9.6/ 19.2/ 38.4/ <u>115.2</u>
	Parity	Parity	None/ Odd/ <u>Even</u>

Page title	Sub-menu title	Description	Values
RS485232	Address	Modbus address	From 1 to 247
	Baudrate	Baud rate (kbps)	<u>9.6/</u> 19.2/38.4/115.2
	Parity	Parity	None/ Odd/ <u>Even</u>
Ethernet	IP add 1/2 IP add 2/2	IP address	
	Subnet 1/2 Subnet 2/2	Subnet mask	From <u>0.0.0.0</u> to 255.255.255.255 **
	Gateway 1/2 Gateway 2/2	Gateway	
	TCP IP Prt	TCP/IP port	From 1 to 9999 (<u>502</u>)

Page title	Sub-menu title	Description	Values
DAGraf	Device id	Instance number	From 0 to 9999 (via keypad) From 0 to 4194302 (via communication) (<u>9999</u>)
BACHE	Baudrate	Baud rate (kbps)	<u>9.6</u> / 19.2/ 38.4/ 57.6/ 76.8
	MAC add	MAC address	From 0 to 127 (<u>1</u>)
BACnet (continues)	Device id	Instance number	From 0 to 9999 (via keypad) From 0 to 4194302 (via communication) (<u>9999</u>)
	FD Enable	Foreign Device enable	Yes/ <u>No</u>
BACnet	BBMD 1/2 BBMD 2/2	BBMD address	From <u>0.0.0.0</u> to 255.255.255.255
	UDP Port	UDP port	From 0001 to FFFF (<u>BAC0</u>)
	Time out s	WM20 time-to-live recording as Foreign Device on specified BBMD server (s)	From 1 to 60 (<u>10</u>)

Page title	Sub-menu title	Description	Values	
Profibus Address		Address	From 2 to 125 (<u>126</u>)	
Virt al 1 ***	Enable	Enable of alarm 1	Yes/ <u>No</u>	
	Variables	Variable controlled by the alarm	All variables controlled by the system except for meters and maximum power values.	
	Set 1	Alarm activation threshold	The unit of measurement and range of admissible	
	Set 2	Alarm activation threshold	values depend on the controlled variable.	
Virt al 1 ***	On delay	Alarm activation delay (s)		
Virt al 2 ***	/irt al 2 ***-Same pages as sub- menu Virt Al 1, for alarm 2.		-	

Page titleSub-menu titleDescription		Values	
	Function	Function of digital output 1	Alar/ Remo/ Puls
	Al link	Associated alarm	Al 1: associates alarm 1/ Al 2: associates alarm 2
	Al status	Normal output status	Ne : normally closed/ Nd : normally open
Dig out 1 ****	Pulse type	Type of energy (kWh or kvarh)	kWh Pos: imported active energy/ kvarh Pos: imported reactive energy/ kWh Neg: exported active energy/ kvarh Neg: exported reactive energy
	Pulse weig	Weight of pulse (kWh/ kvarh per pulse)	-
Dia out 1	Out test	Enable of test re- transmission	Yes/No
****	Power test	Power value for test	From 0.001 W to 9999 MW
Dig out 2 ****	-	Same pages as sub- menu Dig out 1, for digital output 2.	-

	Page title	Sub-menu title	Description	Values
		Reset max	Resets maximum values	
		Reset dmd	Resets average values	
	Reset	Res dmd max	Resets average maximum values	Yes : resets values/ <u>No</u> :
	Reset	Energy pos	Resets values of imported active and reactive energy	cancels reset
		Energy neg	Resets values of exported active and reactive energy	
	End	_	Return to measurement menu	-

NOTE *: for details on the address parameters, see "Address parameters" on page 40.

NOTE **: for details on the filter, see "Filter settings" on page 42.

NOTE ***: for details on the alarm, see "Alarm settings" on page 41. For default values, see "Default values of alarm parameters" on page 27.

NOTE ****: for details on the digital output, see "Configuring digital output modules" on page 45. For default values, see "Default values of digital output parameters" on page 27.

 $26 \qquad \mathsf{WM20} \mid @ \ \mathsf{2019} \mid \textbf{CARLO GAVAZZI Controls SpA} \\$

Default values of alarm parameters						
Alarm Enable Variables Set 1 Set 2 On de						
1	No	VL1N	40	40	0	
2	No	Wsys	40	40	0	

Default values of digital output parameters							
Digital output	Function	Al link	Al status	Pulse type	Pulse weig	Out test	Power test
1	Puls	AI 1	Ne	kWh	0.1	No	0.001
2	Alar	AI 2	Ne	kWh	0.1	No	0.001

Information menu

The information menu contains all pages that display information and parameters entered without password protection.

NOTE: presence of the pages depends on the installed accessory modules.

Page title	Information displayed
12345678	Serial number (page title)Year of manufactureFirmware revision
Conn (2 pages)	 System type (in title) Current transformer ratio (Ct) Voltage transformer ratio (Vt)
Dmd	Interval for average power calculation (min)
Led pulse	Weight of pulse of front LED (kWh/kvarh per pulse)
Run hour	Current threshold for calculating load operating hours (A)

Page title	Information displayed			
	Output function (in title)Specific information for output function:			
	If the function is	the information displayed is		
Pulse / Alarm / Remote	Puls	 unit of measurement of energy transmitted with pulse reference output (out1= output 1, out2 = output 2) weight of pulse (kWh/kvarh per pulse) type of energy transmitted (imported Pos or exported Neg) 		
(2 pages)	Alarm	 reference output (out1 = output 1, out2 = output 2) if the alarm is active, the symbol appears permanently on display 		
	Remote	 reference output (out1= output 1, out2 = output 2) output status (ON = closed, OFF = open) 		

 $28 \qquad \mathsf{WM20} \mid @ \ \mathsf{2019} \mid \textbf{CARLO GAVAZZI Controls SpA} \\$

Page title	Information displayed
Al 1 (2 pages)	 Data of alarm 1 (in title): None: alarm 1 disabled No out: alarm 1 enabled but not associated with a digital output Out 1.NE: alarm associated with digital output 1, normally closed Out 1.ND: alarm associated with digital output 1, normally open Out 2.NE: alarm associated with digital output 2, normally closed Out 2.ND: alarm associated with digital output 2, normally open Alarm activation threshold (Set1) Alarm deactivation threshold (Set2) Controlled variable If the alarm is active, the symbol Appears permanently on display
Al 2 (2 pages)	Same information as pages AI 1 , for alarm 2
Optical	Baud rate of optical port
Com port (2 pages)	Modbus address Baud rate of RS485/RS232 port
IP add ½ IP add 2/2	IP address

Reset menu

The reset menu is made up of two pages used to reset the maximum and average power values respectively (active, apparent and reactive).

Z Ш

Use: how to work

Navigating the menus			
Fig.9	Section	Function	
	Α	Measurement menu	
	В	Information menu	
	С	Reset menu	
	D	Settings menu	

The measurement menu is always displayed on start-up. This menu gives access to the information, reset and parameters menus.

On access to the measurement menu or after 120 seconds of disuse, the measurement page is then displayed as set in the **Home Page**.

A password is requested on access to the settings menu and confirmation on exit.

Common operations		
Operation	Button	
Confirm operation		
View the previous/next page		

 $30 \qquad \mathsf{WM20} \ | \ \texttt{\textcircled{O}} \ \texttt{2019} \ | \ \textbf{CARLO} \ \textbf{GAVAZZI} \ \textbf{Controls} \ \textbf{SpA}$

Operation	Button
Cancel operation	

Specific operations

Measurement menu

Operation	Button
View the next meter	
View the measurement page set in the Home page	
View the value dmd and then Max (if available) and lastly the new instant value	

Settings menu

Operation	Button
Enter the sub-menu/Modify parameter of the page on display	

Operation	Button
Increase a parameter value / View the next value option/ Modify the value in the fields dP and Sign *	
Decrease a parameter value/ View the previous value option/ Modify the value in the fields dP and Sign *	
Move between value fields *	
Exit the sub-menu and view relative title page	

NOTE *: for details, see "Numerical Parameters" on page 39 and "Address parameters" on page 40.

Setting a parameter

Fig.10 Procedure example: how to set **Run hour**=14000.

NOTE: the procedure requires entry of the multiplier **K**. The initial status of the procedure is the **Run hour** page of the settings menu.

Running a pulse transmission test

If the digital output is configured to transmit energy consumption via pulses, a test transmission can be run.

 $32 \qquad \mathsf{WM20} \mid @ \ \mathsf{2019} \mid \textbf{CARLO} \ \textbf{GAVAZZI} \ \textbf{Controls} \ \textbf{SpA}$

- 1. In the settings menu, enter the sub-menu **Dig out 1** or **Dig out 2** (depending on the digital output concerned)
- 2. Ensure that the output is configured for pulse transmission (**Function = Puls**)
- 3. Define the pulse weight (**Pulse weig**) and test power (**Power test**)
- 4. To start the test, set Yes in the Out test page: the test is then run immediately.
- 5. To terminate the test, set **No** in the **Out test** page.

NOTE: during the test, another power value may be set if required. On confirmation of the value, the test transmission is then updated.

Resetting maximum and average values

The analyzer calculates the maximum, average and average maximum value for measurements of active, apparent and reactive power and current. These values can be reset in two ways, with or without password access.

Resetting with password access, from the settings menu

- 1. From any page in the measurement menu, enter the settings menu: the **Password?** page is then displayed.
- 2. Enter the password and confirm.
- 3. Scroll through the pages to display the **Reset** page and enter the sub-menu: the **Reset max** page is then displayed.
- 4. Modify the parameter and select the option **YES**.
- 5. Confirm the operation: the message "Saving" is displayed and the maximum values of active, apparent and reactive energy are reset.
- 6. View the next page (Reset dmd).
- 7. Modify the parameter and select the option **YES**.
- 8. Confirm the operation: the message "Saving" is displayed and all the average values are reset.
- 9. View the next page (**Res dmd max**).

- 10. Modify the parameter and select the option **YES**.
- 11. Confirm the operation: the message "Saving" is displayed and all the average maximum values are reset.

Resetting without password access, from the reset menu

- 1. From any page in the measurement menu, enter the reset menu: the **Reset dmd ?** page is then displayed
- 2. Select the option **YES**.
- 3. Confirm the operation: the message "Resetting" is displayed and then the page **Reset max?**.
- 4. Select the option YES.
- 5. Confirm the operation: the message "Resetting" is displayed and then the page **Res** dmd max?.
- 6. Select the option YES.
- 7.Confirm the operation: the message "Resetting" is displayed and then the measurements page set in the **Home page**.

Resetting total energy meters

The analyzer measures the active and reactive energy, both imported and exported. The total meters are displayed and can be reset directly via the main unit, while partial meters are via communication.

The following section outlines the procedure to simultaneously reset the total meters for active and reactive energy imported and/or exported.

- 1. From any page in the measurement menu, enter the settings menu: the **Password?** page is then displayed.
- 2. Enter the password and confirm.
- 3. Scroll through the pages to display the **Reset** page and enter the sub-menu: the **Reset max** page is then displayed.
- 4. Scroll through the pages to display the page **Energy pos**.

- 5. Modify the parameter and select the option **YES**.
- 6. Confirm the operation: the message "Saving" is displayed and the energy meters for imported active and reactive energy are reset.
- 7. View the next page (Energy neg).
- 8. Modify the parameter and select the option **YES**.
- 9. Confirm the operation: the message "Saving" is displayed and the energy meters for exported active and reactive energy are reset.

Identifying the variable in alarm status

If at least one alarm is present, the symbol **A** blinks on display on the measurement page. To identify which variable is in the alarm status, enter the information menu, on page Al **1/Al 2** and/or **Alarm** and if the relative alarm is active, the symbol **A** remains permanently lit. For a description of the alarms see "Information menu" on page 27.

NOTE: the alarm trips even if the measurement of the variable is in the status EEEE, see "Troubleshooting" on page 35.

Troubleshooting

NOTE: In the event of malfunction, fault, contact the CARLO GAVAZZI branch or distributor in your country.

Measurement

Problem	Cause	Possible solution	
	The settings of CT and/or VT are not correct and therefore the measurement exceeds the maximum admissible value, or is the result of calculations with at least one measurement in the status EEEE	Modify the parameters CT and VT	
The text 'EEEE' appears in place of a measurement	The analyzer is not used within the expected range and therefore the measurement exceeds the maximum admissible value, or is the result of calculations with at least one measurement in the status EEEE	Uninstall the analyzer	
	The analyzer has just been switched on and the set interval for calculating the average power values (default: 15 min) has not yet elapsed	Wait. To modify the interval, go to the page Dmd in the settings menu, see "Settings menu" on page 19	
'Err' appears while the parameter is being set	The value entered is out of range	Check the range of admissible values on the relative page displayed or see "Settings menu" on page 19 and re-enter the value.	

Problem	Cause	Possible solution
The values	Electrical connections are incorrect	Check the connections
are not as expected	The CT and/or VT settings are incorrect	Check the parameters set in the settings menu, see "Settings menu" on page 19

Alarms

Problem	Cause	Possible solution
An alarm has tripped but the measurement has not exceeded the threshold	The value used to calculate the alarm variable is in the status EEEE	Ensure that the settings of parameters CT and VT are correct
	The analyzer is not used within the expected measurement range	Uninstall the analyzer
The alarm is not activated or deactivated as expected	The alarm settings are incorrect	Check the parameters set in the settings menu, see "Settings menu" on page 19

Communication

Problem	Cause	Possible solution	
	The communication module settings are incorrect	Check the parameters in the settings menu, see "Settings menu" on page 19	
Communication not possible with analyzer	The communication module connections are incorrect	Check the connections	
	Communication settings (PLC or third party software) are incorrect	Check communication with the UCS software	

Settings

Problem	Cause	se Possible solution	
It is impossible to change the settings (via keypad)	The password entered is incorrect	Enter the correct password	
	The rotary selector at rear of main unit is in position 7	Set the selector to position 1	
It is impossible to change the settings (via UCS software)	The rotary selector at rear of main unit is in position 7	Set the selector to position 1	
	The user is in the settings menu	Exit the settings menu by pressing for 1.5 s	

Essential information

Numerical parameters

Order of positions

The value of a numerical parameter is made up of six positions: four digits, **dP** and **Sign**.

The button *is* used to select the positions in the following order:



Position dP

In the position dP (decimal point) the buttons and can be used to enable movement of the decimal point and set a multiplier (k x 1000, M x 1000000) in the following order:



Sign position

NOTE: the Sign position is only available for the parameters **Set 1** and **Set 2** in the submenus **Virt Al 1** and **Virt Al 2**.

The value sign can be set in the position Sign. The value is positive by default.

Address parameters

The address parameters are divided into two parts: first part (**HI**) on page **1/2** and second part (**LO**) on page **2/2**. For example the pages **IP add 1/2** and **IP add 2/2** with the address set as 192.168.2.18 will be as follows:



The order of digit selection is from right to left on the firstline and then on the second line.

Alarm settings

WM20 manages two alarms. The following is defined for each alarm:

- variable to be controlled (**Variables**), selectable from all measured electrical variables excluding the maximum power values
- alarm activation threshold (Set1)
- alarm activation delay (On delay)
- alarm deactivation threshold (Set 2)

To set the alarms, see "Settings menu" on page 19, to check the status of set alarms, see "Information menu" on page 27.

Up alarm (Set 1 > Set 2)

If **Set 1** > **Set 2**, the alarm is activated when the controlled variable exceeds the value of **Set 1** for a time equal to **On delay** and is deactivated when it falls below **Set 2**.



Down alarm (Set 1 < Set 2)

If **Set 1** < **Set 2**, the alarm is activated when the controlled variable falls below the value of **Set 1** for a time equal to **On delay** and is deactivated when it rises above **Set 2**.

Z Ш



Filter settings

Operation

A filter can be set to stabilize the display of measurements (both on display and transmitted to external systems).

NOTE: the filter is applied to all measurements in read-only mode and for data transmission, without influencing calculations of energy consumption or intervention of alarms. Two parameters are envisaged:

- **Filter s:** filter intervention range. Value between 0 and 100, expressed as a percentage of the full scale of the variable.
- **Filter co:** filter coefficient. Value between 1 and 255, where 255 is the coefficient that enables maximum stability of the measurements.

If the measured value is outside the range defined by the parameter **Filter s** the filter is not applied.

To set a filter, see "Settings menu" on page 19.

Example

The following section outlines the behavior of the filter for measuring voltage in the version

AV5 with:

- **Filter s** = 2
- Filter co = 2 or 10

On the version AV5 the full scale is 400 V, therefore with **Filter s** = 2 the intervention range is +/- 8 V (2% of 400 V). It should also be noted that the greater the value of **Filter co**, the greater stability is obtained in measurements.

(V))	12 C			
240				
235			T. ST. Standard	
230				
225		-	_	
220	And Real			
215	the state of the s	have		
210				
11	0,5	1	1.5 2	2

Element	Description	
	Intervention range with Filter s = 2	
•	Measured value	
	Measurements displayed with Filter co = 2	
	Measurements displayed with Filter co = 10	
Configuration mode		

Configuration of the accessory modules and settings of the main unit parameters can be performed before or after installation, but only when the icon **i** is displayed.

Parameters for the accessory modules can only be set when the modules are connected

to the main unit.

The parameters can be set in two ways:

- via the keypad of the main unit, see "Settings menu" on page 19
- using the UCS configuration software via the communication module with Modbus protocol, see "Communication module overview" on page 56 or front optical port via OptoProg (see relative documentation).

Enabling the accessory modules

The accessory modules must be enabled. The enable command can be automatic or manual.

Enable	Description	Modules
Automatic	The module is automatically detected and enabled	 M C ETH M C BAC IP MC BAC MS M C PB
Manual	The module must be enabled via the settings menu, see "Settings menu" on page 19	• M O R2 • M O O2 • M C 485232 *

NOTE *: module enabled only if no other communication module has been installed.

Configuring digital output modules

The digital outputs of modules M O R2 and M O O2 canbe assigned with three different functions:

Function	Description	Parameters
Alar	Alarm: output associated with an alarm and directly managed by WM20	 Alarm associated (Al link) * Status of the digital output in non-alarm status (Al status)
Remo	Remote control: output status managed via communication	-
Puls	Pulse: pulse transmission output on active or reactive, imported or exported energy consumption. A pulse transmission test can be run.	 Type of energy (Pulse type) Pulse weight (Pulse weig) Test transmission enable (Out test) Power value for test (Power test)

NOTE *: the alarms must be set in pages Virt al 1 and Virt al 2.

To set alarm parameters, see "Settings menu" on page 19.

Maintenance and disposal

Cleaning

Use a slightly dampened cloth to clean the display. Do not use abrasives or solvents.

Responsibility for disposal

The product must be disposed of at the relative recycling centres specified by the government or local public authorities. Correct disposal and recycling will contribute to the prevention of potentially harmful consequences to the environment and persons.



Common specifications

General features			
Material	Front: ABS, self-extinguishing V-0 (UL 94) Back and accessory modules: PA66, self-extinguishing V-0 (UL 94)		
Protection degree	Front: IP65 NEMA 4x NEMA 12 Terminals: IP20		
Terminals	Type: detachable Section: max. 2.5 mm2 Torque: 0.5 Nm		
Overvoltage category	Cat. III		
Pollution degree	2		
Noise rejection (CMRR)	100 dB, from 42 to 62 Hz		
Insulation	double electrical insulation on areas accessible to the user. For insulation between inputs and outputs, see "Input and output insulation" on page 48.		

Input and output insulation

NOTE: test conditions: 4 kV rms ac for one minute.

Туре	Power supply (H or L) [kV]	Measurement inputs [kV]	Digital outputs [kV]	Serial port [kV]	Ethernet port [kV]
Power supply (H or L)	-	4	4	4	4
Measurement inputs	4	-	4	4	4
Digital outputs	4	4	-	4	4
Serial port	4	4	4	-	NP
Ethernet port	4	4	4	NP	-

Breakdown

- NA : combination not possible
- **4:** 4 kV rms insulation (EN 61010-1, IEC 60664-1, overvoltage category III, pollution degree 2, double insulation on system with maximum 300 Vrms to ground)

Environmental specifications			
Operating temperature	From -25 to +55 °C/from -13 to +131 °F		
Storage temperature	From -30 to +70 °C/from –22 to +158 °F		

NOTE: R.H. < 90 % non-condensing @ 40 °C / 104 °F.

 $48 \qquad \mathsf{WM20} \ | \ \texttt{\textcircled{O}} \ \texttt{2019} \ | \ \textbf{CARLO} \ \textbf{GAVAZZI} \ \textbf{Controls} \ \textbf{SpA}$

Main unit specifications

General features			
Mounting	Panel mounting		
Dimensions (mm)	See figure		





Electrical specifications

Voltage inputs

	AV4	AV5	AV6	AV7
Voltage connection	Direct or via VT/PT			
VT/PT transformation ratio	From 1 to 9999			
Rated voltage L-N (from Un min to Un max)	From 220 to 400 V	From 220 to 400 V	From 57.7 to 133 V	From 57.7 to 133 V
Rated voltage L-L (from Un min to Un max)	From 380 to 690 V	From 380 to 690 V	From 100 to 230 V*	From 100 to 230 V*
Voltage tolerance	-20%, + 15%			
Overload	Continuous: 1.2 Un max For 500 ms: 2 Un max			
Input impedance	>1.6 MΩ			
Frequency	From 40 to 440 Hz			

NOTE*: in case of two-phase or wild leg system: rated voltage L-L up to 240 V

Current inputs

	AV4	AV5	AV6	AV7
Current connection		Via	СТ	
CT transformation ratio	From 1 to 9999			
Rated current (In)	1 A	5 A	5 A	1 A
Minimum current (Imin)	0.01 A	0.05 A	0.05 A	0.01 A
Maximum current (Imax)	2 A	6 A	6 A	2 A
Start-up current (Ist)	1 mA	5 mA	5 mA	1 mA
Overload	Continuous: Imax For 500 ms: 20 Imax			
Input impedance	< 0.2 VA			
Maximum CT x VT ratio	9999 x 9999			

Measurement accuracy		
Current		
From 0.05 In to Imax	±(0.5% rdg + 2dgt)	
From 0.01 In to 0.05 In	±(0.2% rdg + 2dgt)	
Phase-phase voltage		
From Un min -20% to Un max + 15%	±(0.5% rdg +1dgt)	
Phase-neutral voltage		
From Un min -20% to Un max + 15%	±(0.2% rdg +1dgt)	
Active and apparent power		
From 0.05 In to Imax (PF=0.5L, 1, 0.8C)	±(0.5% rdg +1dgt)	
From 0.01 In to 0.05 In (PF=1)	±(1% rdg +1dgt)	
Reactive power		
From 0.1 In to Imax (sinφ=0.5L, 0.5C) From 0.05 In to Imax (sinφ=1)	±(1% rdg + 1 dgt)	
From 0.05 In to 0.1 In (sinφ=0.5L, 0.5C) From 0.02 In to 0.05 In (PF=1)	±(1.5% rdg + 1 dgt)	

 $52 \qquad \mathsf{WM20} \mid @ \ \mathsf{2019} \mid \textbf{CARLO GAVAZZI Controls SpA}$

Power factor	±[0.001+0.5%(1 – PF rdg)]	
Active energy	Class 0.5S (EN62053-22, ANSI C12.20)	
Reactive energy	Class 2 (EN62053-23, ANSI C12.1)	
тно	±1%	
Frequency		
From 40 to 65 Hz	±(0.02% rdg + 1 dgt)	
From 65 to 340 Hz	±(0.05% rdg + 1 dgt)	
From 340 to 440 Hz	±(0.1% rdg + 1 dgt)	

Power supply			
	Н	L	
Auxiliary power supply	From 100 to 240 V ac/dc ± 10%	From 24 to 48 V ac/dc ± 15%	
Consumption	10 W, 20 VA		

LED				
	Red. Weight: proportional to energy consumption and depending on the CT and VT/PT ratio product (16 Hz maximum frequency):			
	Weight (kWh per pulse) CT*VT/PT			
	0.001	< 7		
	0.01	From 7.1 to 70		
Front	0.1	From 70.1 to 700		
	1	From 700.1 to 7000		
	10	From 7001 to 70 k		
	100	> 70.01 k		
	The page Led pulse in the information menu displays the weight of the pulse.			
Back	Green. Lit when WM20 is powered.			

 $54 \qquad \mathsf{WM20} \mid @ \ \mathsf{2019} \mid \textbf{CARLO GAVAZZI Controls SpA} \\$

Digital output module specifications

General features		
Mounting	On main unit	
Dimensions (mm)	See figure	
Power supply	Self power supply via local bus	
Static output module (M	0 02)	

Static output module (M O OZ)		
Maximum number of outputs	2	
Туре	Opto-mosfet	
Features	V _{oN} : 2.5 V dc, 100 mA max V _{OFF} : 42 V dc max	
Configuration parameters	Settings menu, sub-menus Dig out 1 and Dig out 2 , see "Settings menu" on page 19	
Configuration mode	Via keypad or UCS software	

Relay output module (M O R2)		
Maximum number of outputs	2	
Туре	SPDT relay	
Features	AC1: 5 A @ 250 V ac AC15: 1 A @250 V ac	
Configuration parameters	Settings menu, sub-menus Dig out 1 and Dig out 2 , see "Settings menu" on page 19	
Configuration mode	Via keypad or UCS software	

Communication module overview

General features		
Mounting	On main unit (with or without digital output module)	
Dimensions (mm)	See figure	
Power supply	Self power supply via local bus	



56	WM20 ©	2019 CARLO	GAVAZZI	Controls	SpA
----	----------	--------------	---------	----------	-----

NOTE: in case of wild leg system (three-phase, four-wire delta) one of the line-to-neutral voltage can exceed the rated range in the table up to:

• 415 V (AV4, AV5)



• 208 V (AV6, AV7)



M C 485232 module

RS485 port

Protocol	Modbus RTU	
Devices on the same bus	Max 160 (1/5 unit load)	
Communication type	Multidrop, bidirectional	
Connection type	2 wires, maximum distance 1000 m	
Configuration parameters	Settings menu, sub-menu RS485232 , see "Settings menu" on page 19	
Configuration mode	Via keypad or UCS software	

RS232 port

Protocol	Modbus RTU
Communication type	Two-way
Connection type	3 wires, maximum distance 15 m
Configuration parameters	Settings menu, sub-menu RS485232 , see "Settings menu" on page 19
Configuration mode	Via keypad or UCS software

NOTE: the RS485 and RS232 ports are alternative.

LED

	Communication status:
Meaning	Yellow: receiving
	Green: transmitting

M C ETH module

Ethernet port

Protocol	Modbus TCP/IP
Client connections	Maximum 5 simultaneously
Connection type	RJ45 connector (10 Base-T, 100 Base-TX), maximum distance 100 m
Configuration parameters	Settings menu, sub-menu Ethernet , see "Settings menu" on page 19
Configuration mode	Via keypad or UCS software

M C BAC IP module

Ethernet port

Protocols	BACnet IP (reading) Modbus TCP/IP (reading and configuration)
Client connections	(Modbus only) Maximum 5 simultaneously
Connection type	RJ45 connector (10 Base-T, 100 Base-TX), maximum distance 100 m

ΕN

Configuration parameters	Settings menu, sub-menus Ethernet and BACnet , see "Settings menu" on page 19
Configuration mode	Via keypad or UCS software

M C BAC MS module

RS485 port

Protocol	BACnet MS/TP (measurement reading and object description writing)	
Communication type	Multidrop, one-way	
Connection type	2 wires, maximum distance 1000 m	
Supported services	"I-have", "I-am", "Who-has", "Who-is", "Read-property (multiple)"	
Supported objects	Type 2 (analogue value including COV property), type 5 (binary value, for alarm transmission), type 8 (device)	
Configuration parameters	ion parameters Settings menu, sub-menu BACnet , see "Settings menu" on page 19	
Configuration mode	Via keypad or UCS software	

Ethernet port

Protocols	Modbus TCP/IP (configuration)
Client connections	Maximum 5 simultaneously
Connection type	RJ45 connector (10 Base-T, 100 Base-TX), maximum distance 100 m

Configuration parameters	Settings menu, sub-menu Ethernet , see "Settings menu" on page 19
Configuration mode	Via keypad or UCS software

LED

	Communication status:
Meaning	Yellow: receiving
	Green: transmitting

M C PB module

Profibus port

Protocols	Profibus DP V0 slave
Connection type	9-pin D-sub RS485 socket
Configuration parameters	Settings menu, sub-menu Profibus , see "Settings menu" on page 19 Other parameters available with the UCS software via serial communication (see relative illustration sheet)
Configuration mode	Via keypad or UCS software

Micro-USB port

Protocols	Modbus RTU
Туре	USB 2.0 (USB 3.0 compatible)
Connection type	Micro-USB B
Baud rate	Any (maximum 115.2 kbps)
Address	1

LED

Red	Communication status between module and main unit: • Lit: communication error • Off: communication OK
Green	Communication status between module and Profibus master:Lit: data exchange in progressBlinking: communication readyOff: communication error

Conformity

Directives	 2014/35/EU (Low Voltage) 2014/30/EU (Electromagnetic compatibility) 2011/65/EU (Electric-electronic equipment hazardous substances)
Standards	 Electromagnetic compatibility (EMC) - emissions and immunity: EN62052-11 Electrical safety: EN61010-1 Metrology: EN62053-22, EN62053-23 Pulse outputs: IEC62053-31, DIN43864

Approvals

C C CUUS LISTED

Firmware revision

Firmware revision	Option/function
	A max, Admd, A dmd max.
	W dmd max, VA dmd max, var dmd max.
	Suitable for Wild leg system installation.

Download

The site www.productselection.net enables users to download:

- UCS software
- datasheets and manual of the WM20 in PDF format
- · other files useful for accessory modules



FIGURES

FIGURE

ABBILDUNGEN

FIGURAS

FIGURER

FIGURES

381













 $\mathsf{WM20} \mid @ \ \texttt{2019} \mid \textbf{CARLO GAVAZZI Controls SpA} \qquad \textbf{383}$









 $\mathsf{WM20} \mid @ \ \texttt{2019} \mid \textbf{CARLO GAVAZZI Controls SpA} \qquad 385$



10





via Safforze, 8 32100 Belluno (BL) - Italy

www.gavazziautomation.com info@gavazzi-automation.com info: +39 0437 355811 fax: +39 0437 355880

WM20